

Stainless Steel Trim Tab Kits (Control Switch Not Included)

Lectrotab Kit without Control Switch	Kit Contains these Parts
XKA9X9	2 – Actuators with 23' (7m) cable
XKA9X12	2 – Flat Stainless Steel Tabs, 12 Gauge
XKA9X18	
XKA9X24	
XKA9X30	
XKA9X36	
XKA12X9	
XKA12X12	
XKA12X18	
XKA12X24	
XKA12X30	
XKA12X36	
XKA12X42	



Stainless Steel Trim Tab Kit Model Number

<p>XK</p> <p>XK = 23'(7m) Actuator Cable K = 6'(1.8m) Actuator Cable</p>	<p>A</p> <p>No Designation = Control Not Included</p> <p>A = Standard Actuator 12vdc (A-BK-13), 2.25" (57mm) stroke, 8 second stroke time B = Standard Actuator 24vdc (B-BK-13), 2.25" (57mm) stroke, 8 second stroke time C & D = See Note Below</p>	<p>12</p> <p>1st Number = Tab Chord Length (inches)</p>	<p>X</p> <p>12</p> <p>2nd Number = Tab Width Across Transom (inches)</p>
---	--	--	--

Note:

Actuators are also available with a 4 second stroke time. 4 second stroke time model numbers begin with the letter "C" for 12vdc and "D" for 24vdc.

Please note that Lectrotab recommends using the 8 second stroke time for a smoother, more controlled boat response to tab adjustments.